



# Answer Wood Stove

## Owner's Manual



- Freestanding Stove
- Mobile-Home Approved
- Alcove Approved
- Hearth-Stove Approved
- Masonry Fireplace Insert
- Zero-Clearance (Metal) Fireplace Insert

Save these instructions for future reference

**WARNING**



**HOT GLASS WILL  
CAUSE BURNS.  
DO NOT TOUCH GLASS  
UNTIL COOLED.  
NEVER ALLOW CHILDREN  
TO TOUCH GLASS.**

### SAFETY NOTICE:

If this appliance is not properly installed, a house fire may result. For your safety, follow the installation directions. Contact local building or fire officials about restrictions and installation inspection requirements in your area.



**TRAVIS INDUSTRIES  
HOUSE OF FIRE**

© Copyright 2010, T.I.  
\$10.00 100-01166  
4100806



**Listed**

Tested to: ULC 1482

## Introduction

We welcome you as a new owner of a Lopi Answer wood-burning stove. In purchasing a Lopi Answer you have joined the growing ranks of concerned individuals whose selection of an energy system reflects both a concern for the environment and aesthetics. The Lopi Answer is one of the finest appliances the world over. This manual will explain the installation, operation, and maintenance of this appliance. Please familiarize yourself with the Owner's Manual before operating your appliance and save the manual for future reference. Included are helpful hints and suggestions which will make the installation and operation of your new appliance an easier and more enjoyable experience. We offer our continual support and guidance to help you achieve the maximum benefit and enjoyment from your appliance.

## Important Information

No other Lopi Answer appliance has the same serial number as yours. The serial number is stamped onto the label on the back of the appliance.

This serial number will be needed in case you require service of any type.

Model: Lopi Answer ND

Serial Number: \_\_\_\_\_

Purchase Date: \_\_\_\_\_

Purchased From: \_\_\_\_\_

### Mail your Warranty Card Today, and Save Your Bill of Sale.

To receive full warranty coverage, you will need to show evidence of the date you purchased your appliance. Do not mail your Bill of Sale to us.


We suggest that you attach your Bill of Sale to this page so that you will have all the information you need in one place should the need for service or information occur.



We suggest that our woodburning hearth products be installed and serviced by professionals who are certified in the U.S. by the National Fireplace Institute® (NFI) as NFI Woodburning Specialists or who are certified in Canada by Wood Energy Technical Training (WETT).



|                                                                  |                  |                                                                |                  |
|------------------------------------------------------------------|------------------|----------------------------------------------------------------|------------------|
| <b><u>Introduction .....</u></b>                                 | <b><u>2</u></b>  | <b><u>Opening the Door .....</u></b>                           | <b><u>23</u></b> |
| <b><u>Important Information.....</u></b>                         | <b><u>2</u></b>  | <b><u>Starting a Fire.....</u></b>                             | <b><u>24</u></b> |
| <b><u>Installation Options.....</u></b>                          | <b><u>6</u></b>  | <b><u>Adjusting the Burn Rate.....</u></b>                     | <b><u>25</u></b> |
| <b><u>Features .....</u></b>                                     | <b><u>6</u></b>  | Approximate Air Control Settings.....                          | 25               |
| <b><u>Heating Specifications.....</u></b>                        | <b><u>6</u></b>  | <b><u>Ash Removal .....</u></b>                                | <b><u>25</u></b> |
| <b><u>Dimensions .....</u></b>                                   | <b><u>6</u></b>  | <b><u>Optional Blower Operation .....</u></b>                  | <b><u>26</u></b> |
| <b><u>Emissions .....</u></b>                                    | <b><u>6</u></b>  | <b><u>Re-Loading the Stove .....</u></b>                       | <b><u>26</u></b> |
| <b><u>Planning The Installation.....</u></b>                     | <b><u>7</u></b>  | <b><u>Overnight Burn .....</u></b>                             | <b><u>26</u></b> |
| Preparation for Installation.....                                | 7                | <b><u>Normal Operating Sounds .....</u></b>                    | <b><u>26</u></b> |
| Additional Accessories Needed for Installation .....             | 7                | <b><u>Hints for Burning .....</u></b>                          | <b><u>27</u></b> |
| Stove Installation Considerations .....                          | 7                | <b><u>Selecting Wood .....</u></b>                             | <b><u>27</u></b> |
| <b><u>Floor Protection Requirements .....</u></b>                | <b><u>8</u></b>  | Why Dry Wood is Key .....                                      | 27               |
| <b><u>Stove Placement Requirements .....</u></b>                 | <b><u>8</u></b>  | Wood Cutting and Storage.....                                  | 27               |
| <b><u>Clearances .....</u></b>                                   | <b><u>8</u></b>  | <b><u>Troubleshooting .....</u></b>                            | <b><u>28</u></b> |
| Top View - Straight Installation.....                            | 9                | <b><u>Daily Maintenance (while stove is in use) .....</u></b>  | <b><u>29</u></b> |
| Top View - Corner Installation .....                             | 9                | Remove Ash (if necessary) .....                                | 29               |
| <b><u>Chimney Connector Requirements .....</u></b>               | <b><u>10</u></b> | Clean the Glass (if necessary) .....                           | 29               |
| <b><u>Chimney Requirements .....</u></b>                         | <b><u>11</u></b> | <b><u>Monthly Maintenance .....</u></b>                        | <b><u>30</u></b> |
| <b><u>Chimney Termination Requirements .....</u></b>             | <b><u>12</u></b> | Door and Glass Inspection.....                                 | 30               |
| <b><u>Outside Air Requirements .....</u></b>                     | <b><u>12</u></b> | Creosote - Formation and Need for Removal .....                | 30               |
| <b><u>Alcove Installation Requirements .....</u></b>             | <b><u>13</u></b> | <b><u>Yearly Maintenance .....</u></b>                         | <b><u>31</u></b> |
| <b><u>Mobile Home Requirements .....</u></b>                     | <b><u>14</u></b> | Touch Up Paint .....                                           | 31               |
| Standard Ceiling with a Factory Built Chimney .....              | 15               | Cleaning the Air Duct and Blower (if applicable) .....         | 31               |
| Cathedral Ceiling with a Factory Built Chimney .....             | 15               | Firebrick and Baffle Inspection.....                           | 31               |
| Exterior Factory Built Chimney .....                             | 16               | <b><u>Door Parts .....</u></b>                                 | <b><u>32</u></b> |
| Hearth Stove Positive Connection .....                           | 16               | Replacing the Glass .....                                      | 32               |
| Hearth Stove Direct Connection .....                             | 17               | Replacing the Door Gasket.....                                 | 32               |
| Interior or Exterior Masonry Chimney .....                       | 17               | Replacing the Door Handle .....                                | 32               |
| <b><u>Planning The Installation.....</u></b>                     | <b><u>18</u></b> | <b><u>Firebox Parts .....</u></b>                              | <b><u>33</u></b> |
| Preparation for Installation.....                                | 18               | Floor and Side Firebrick Removal & Replacement.....            | 33               |
| Additional Accessories Needed for Installation .....             | 18               | <b><u>Baffle Removal &amp; Replacement.....</u></b>            | <b><u>34</u></b> |
| Installation Considerations.....                                 | 18               | <b><u>Air Tube Removal &amp; Replacement .....</u></b>         | <b><u>34</u></b> |
| <b><u>Fireplace Requirements .....</u></b>                       | <b><u>19</u></b> | Listing Label .....                                            | 36               |
| <b><u>Fireplace Altered Tag.....</u></b>                         | <b><u>19</u></b> | <b><u>Door Shell Installation.....</u></b>                     | <b><u>37</u></b> |
| <b><u>Insert Placement Requirements .....</u></b>                | <b><u>20</u></b> | Nickel (Cast Iron) Doors Only .....                            | 38               |
| <b><u>Hearth Requirements.....</u></b>                           | <b><u>20</u></b> | <b><u>Stove Leg Installation.....</u></b>                      | <b><u>40</u></b> |
| <b><u>Masonry Fireplace Requirements.....</u></b>                | <b><u>20</u></b> | <b><u>Pedestal (Part # 99200106).....</u></b>                  | <b><u>41</u></b> |
| <b><u>Zero-Clearance (Metal) Fireplace Requirements.....</u></b> | <b><u>21</u></b> | Using Outside Air with the Pedestal.....                       | 41               |
| <b><u>Drafting Performance .....</u></b>                         | <b><u>21</u></b> | <b><u>Rear Blower Installation (Part # 99000138) .....</u></b> | <b><u>42</u></b> |
| <b><u>Leveling Bolt Installation.....</u></b>                    | <b><u>21</u></b> | <b><u>Outside Air Boot Installation .....</u></b>              | <b><u>43</u></b> |
| Insert with Positive Connection.....                             | 22               | <b><u>Surround Panels .....</u></b>                            | <b><u>44</u></b> |
| Insert with Direct Connection (Masonry Fireplace) .....          | 22               | Rectangular Panels: .....                                      | 44               |
| <b><u>Safety Notice .....</u></b>                                | <b><u>23</u></b> | Arched Panels (Part # 99300108).....                           | 44               |
| <b><u>Before Your First Fire .....</u></b>                       | <b><u>23</u></b> | Installation Instructions.....                                 | 44               |
| Curing the Paint .....                                           | 23               | <b><u>Front Blower (part # 99000128) .....</u></b>             | <b><u>46</u></b> |
| Over-Firing the Stove.....                                       | 23               | To Switch The Power Cord To The Left Side: .....               | 46               |
|                                                                  |                  | Installation Instructions.....                                 | 46               |



The viewing door must be closed and latched during operation.

Smoke from this appliance may activate a smoke detector when the door is open.

Never block free airflow through the air vents on this appliance.



Gasoline or other flammable liquids must never be used to start the fire or "Freshen Up" the fire. Do not store or use gasoline or other flammable liquids in the vicinity of this appliance.




This appliance is designed and approved for the burning of cord wood only. Do not attempt to burn any other type of fuel other than cord wood in this appliance, it will void all warranties and safety listings.



Ashes must be disposed in a metal container with a tight lid and placed on a non-combustible surface well away from the home or structure.



Do not touch the appliance while it is hot and educate all children of the danger of a high-temperature appliance. Young children should be supervised when they are in the same room as the appliance.



Keep furniture, drapes, curtains, wood, paper, and other combustibles a minimum of 36" away from the front of the appliance.



This appliance must be properly installed to prevent the possibility of a house fire. The instructions must be strictly adhered to. Do not use makeshift methods or compromise in the installation.




Contact your local building officials to obtain a permit and information on any installation restrictions or inspection requirements in your area. Notify your insurance company of this appliance as well.




Inspect the chimney connector and chimney at least twice monthly and clean if necessary. Creosote may build up and cause a house fire.


Do not connect this appliance to any chimney serving another appliance.




This appliance must be connected to a listed high temperature (UL 103 HT) residential type chimney or an approved masonry chimney with a standard clay tile, or stainless steel liner.




When installed in a mobile home, this appliance must be bolted to the floor, have outside air, and not be installed in the bedroom (Per H.U.D. requirements). Check with local building officials.



Do not place clothing or other flammable items on or near this appliance.




Never try to repair or replace any part of this appliance unless instructions are given in this manual. All other work must be done by a trained technician.




Do not make any changes or modifications to an existing masonry fireplace or chimney to install this appliance.

Do not make any changes to the appliance to increase combustion air.



Allow the appliance to cool before carrying out any maintenance or cleaning.




Overfiring the appliance may cause a house fire. If a unit or chimney connector glows, you are overfiring.



Maintain the door and glass seal and keep them in good condition.

Do not operate this heater with broken or missing glass. Avoid placing wood against the glass when loading. Do not slam the door or strike the glass.



Do not use a grate or other device to elevate the fire off of the firebox floor. Burn the fire directly on the bricks.



Do not throw this manual away. This manual has important operating and maintenance instructions that you will need at a later time. Always follow the instructions in this manual.



**Travis Industries, Inc. grants no warranty, implied or stated, for the installation or maintenance of your appliance, and assumes no responsibility of any consequential damage(s).**

### Installation Options

- Freestanding
- Freestanding in an Alcove
- Freestanding in a Mobile Home
- Masonry Fireplace Insert
- Zero-Clearance (Metal) Fireplace Insert

### Features

- EPA Phase II Approved
- 1.6 Cubic Foot Firebox Volume
- Single Operating Control
- Accepts Logs Up to 18" Long
- Steel Plate Construction (1/4" & 3/16")
- Heavy Duty Refractory Firebrick
- Optional High-Tech Blower

### Heating Specifications

|                                                        |                                               |
|--------------------------------------------------------|-----------------------------------------------|
| Approximate Maximum Heating Capacity (in square feet)* | 750 to 1,400 (stove)<br>750 to 1,200 (insert) |
| Maximum BTU's per Hour (Cord Wood Calculation)         | 66,800                                        |
| Maximum Burn Time                                      | Up to 8 Hours                                 |

\* Heating capacity will vary depending on the home's floor plan, degree of insulation, and the outside temperature. It is also affected by the quality and moisture level of the fuel.

### Dimensions




Figure 1

(a) Measure all side, corner, and back clearances from the stove top.

### Emissions

4.4 Grams Per Hour (EPA Phase II Approved) – Tests conducted by E.E.S.P.C.

## SAFETY NOTICE:

Please read this entire manual before you install and use your new room heater. Failure to follow instructions may result in property damage, bodily injury, or even death. Contact local building or fire officials about restrictions and installation inspection requirements in your area.

## Planning The Installation



We suggest that you have an authorized Travis Industries dealer install your stove. If you install the stove yourself, your authorized dealer should review your installation plans.



Check with local building officials for any permits required for installation of this stove and notify your insurance company before proceeding with installation.

## Preparation for Installation

- Check for damage to the exterior of the stove (dents should be reported, scratches can be fixed by applying touch up paint).
- Check the interior of the firebox (replace cracked firebrick and make sure baffle is in place).



The stove can be lightened by removing the firebricks and baffle (pg 33) - replace before operation.

## Additional Accessories Needed for Installation

- Door Shell (Black 99300195 Brass 99300196 or Pewter 99300197 - see pg 37)
- Legs or Pedestal

## Stove Installation Considerations

The table below details the six most common types of installations and the considerations for each type. Alternative methods of installation are available if they comply with local building codes.

| Installation Type                                                         | Considerations                                                                                                                                                                                                                               |
|---------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Standard Ceiling with a Factory Built Chimney (Page 15)                   | <ul style="list-style-type: none"> <li>• Requires ceiling and roof penetration</li> <li>• Provides best draft</li> </ul>                                                                                                                     |
| Cathedral Ceiling with a Factory Built Chimney (Page 15)                  | <ul style="list-style-type: none"> <li>• Cathedral style chimney support required</li> <li>• Provides best draft</li> </ul>                                                                                                                  |
| Exterior Factory Built Chimney (Page 16)                                  | <ul style="list-style-type: none"> <li>• Uses two elbows to route chimney outside</li> <li>• Exterior chimney is hidden from the room</li> <li>• Elbows reduce draft</li> <li>• Optional exterior chase reduces cold air blockage</li> </ul> |
| Hearth Stove Positive Connection (Page 16)                                | <ul style="list-style-type: none"> <li>• Utilizes existing masonry or zero clearance (metal) chimney</li> <li>• Provides good draft due to full reline</li> <li>• Easier to clean than direct or horizontal hearth stove</li> </ul>          |
| Hearth Stove Direct Connection (Page 17)<br><u>NOT APPROVED IN CANADA</u> | <ul style="list-style-type: none"> <li>• Utilizes existing masonry or zero clearance (metal) chimney</li> <li>• Requires construction of a "block-off plate"</li> <li>• Draft reduced due to elbows &amp; chimney cross section</li> </ul>   |
| Interior Masonry Chimney (Page 17)<br><u>NOT APPROVED IN CANADA</u>       | <ul style="list-style-type: none"> <li>• Utilizes existing masonry chimney (not approved for zero clearance (metal) fireplaces)</li> </ul>                                                                                                   |

### Floor Protection Requirements

- Stove must be placed on the Travis Industries legs or Pedestal.
- Floor protection must extend to the sides, rear, and front of the stove (see "Clearances" below for minimum floor protection).
- Floor protection must be non-combustible and at least .018" thick (26 guage).

### Stove Placement Requirements



Clearances may be reduced by methods specified in NFPA 211, listed wall shields, pipe shields, or other means approved by local building or fire officials.

- Stove must be placed so that no combustibles are within, or can swing within (e.g. drapes, doors), 36" of the front of the stove
- If the stove is placed in a location where the ceiling height is less than 7', it must follow the requirements in the section "Alcove Installation Requirements"
- Must maintain the clearances to combustibles listed below (drywall, furniture, etc.):

### Clearances

- The following clearances must be met (see Figure 2 and Figure 3)

| Clearance Requirements: |                             | Singlewall Connector                 |       | Reduced Clearance*                   |       |
|-------------------------|-----------------------------|--------------------------------------|-------|--------------------------------------|-------|
| A                       | Sidewall to stove           | 18"                                  | 458mm | 13"                                  | 331mm |
| B                       | Backwall to stove           | 16.5"                                | 420mm | 9"                                   | 229mm |
| C                       | Cornerwall to stove         | 10"                                  | 254mm | 7.5"                                 | 191mm |
| D                       | Connector to sidewall       | 27"                                  | 686mm | 21.5"                                | 547mm |
| E                       | Connector to backwall       | 19.5"                                | 496mm | 11.5"                                | 293mm |
| F                       | Connector to cornerwall     | 19.5"                                | 496mm | 16.5"                                | 420mm |
| G                       | Side & Rear Floor Protector | 6" 153mm (US)<br>8" 204mm (Canada)   |       | 6" 153mm (US)<br>8" 204mm (Canada)   |       |
| H                       | Front Floor Protector       | 16" 407mm (US)<br>18" 458mm (Canada) |       | 16" 407mm (US)<br>18" 458mm (Canada) |       |

\*Reduced clearance installations require one of the chimneys and connectors listed below:

AMERI-TEC model DCC with model HS chimney  
 DURAVENT model DVL with DURATEC or DURA-PLUS chimney  
 GSW Super Chimney Twenty-One connected directly to appliance  
 I.C.C. Excel (2100-2 Can.) (103-HT USA) chimney with HP connector  
 METALFAB model DW connector with TG chimney  
 OLIVER MACLEOD PROVENT model PV connector with model 3103 chimney  
 SECURITY model DP connector with SECURITY model ASHT or S2100 chimney  
 SELKIRK METALBESTOS model DS connector with model SSII chimney  
 Standard Masonry Chimney with any one of the above listed connectors

**NOTE:** Reduced clearance connectors may not connect to the flue collar – an appliance adapter may be required.

**NOTE:** Standard residential installations with reduced clearance connector may use the clearance determined by the manufacturer of the connector for the connector to wall clearance or the clearance listed in this manual. Offsets must be used to maintain the stove to wall clearance.

## Top View - Straight Installation




Figure 2

## Top View - Corner Installation

- i** Measure rear and side clearances from the nearest edge of the stove top.
- j** NOTE: Vent diameter varies depending on brand and model.
- k** Measure front clearances from the face of the stove (unibody).




Figure 3

### Chimney Connector Requirements


---

- Chimney connector is required from the flue collar of the stove to the factory-built chimney or masonry chimney.
- The chimney connector must be 6" diameter and a minimum 24 gauge black steel, or one of the reduced-clearance connectors listed on page 8.

NOTE: Aluminum or galvanized steel is not allowed – these materials can not withstand the flue temperatures and may give off toxic fumes when heated.

NOTE: Standard residential installations may use single-wall connector (Mobile-Homes may **not**).

- The chimney connector may not pass through a ceiling, attic, roof, closet, or any other concealed space (use listed UL 103 HT chimney – see "Chimney Requirements for details). **DO NOT USE CONNECTOR PIPE AS CHIMNEY.**
- IN CANADA: Where passage through a wall, or partition of combustible construction is desired, the installation shall conform to CAN/CSA-B365, Installation Code for Solid-Fuel-Burning Appliances and Equipment.
- The chimney connector should be as short and direct as possible. No more than 180° of elbows (two 90° elbows, or two 45° & one 90° elbow, etc.) may be used for the entire system (connector and chimney).. Horizontal runs should slope upwards 1/4" per foot and be a maximum 36" long.
- The chimney connector must be installed with the crimped end pointing downwards. This prevents creosote from leaking to the exterior of the pipe.



- The chimney connector must be fastened to the stove and each adjoining section (and chimney).
- Standard residential installations may use single-wall connector (Mobile-Homes may **not**)
- Standard residential installations with reduced clearance connector may use the clearance determined by the manufacturer of the connector for the connector to wall clearance or the clearance listed in this manual. Offsets must be used to maintain the stove to wall clearance. Mobile homes must use the clearances listed in this manual under "Additional Requirements for Mobile Home Installations".

## Chimney Requirements

- DO NOT CONNECT THIS UNIT TO A CHIMNEY FLUE SERVING ANOTHER APPLIANCE.
- DO NOT CONNECT TO OR USE IN CONJUNCTION WITH ANY AIR DISTRIBUTION DUCTWORK UNLESS SPECIFICALLY APPROVED FOR SUCH INSTALLATIONS.
- IN CANADA: This appliance must be connected to a factory-built chimney conforming to CAN/ULC-S629, Standard for 650°C Factory-Built Chimneys.
- UL 103 HT Chimney must be used from the first ceiling or floor penetration to the chimney cap.
- Use 6" diameter type UL 103 HT chimney from one manufacturer (do not mix brands) or code approved masonry chimney with a flue liner.
- Chimney must be fastened to each adjoining section.
- Follow the chimney manufacturer's clearances and requirements.
- Use the chimney manufacturer's fire stops, attic guards, roof supports, and flashings when passing through a ceiling (see "b" below).
- No more than 180° of elbows (two 90° elbows, or two 45° & one 90° elbow, etc.) may be used for the entire system (connector and chimney).

NOTE: Additional elbows may be allowed if draft is sufficient. Whenever elbows are used the draft is adversely affected. Additional chimney height may be required to boost draft.

- (a) Min. System Height 15'  
Max. System Height 33'
- (b) Roof Penetration and Termination (see chimney manufacturer's requirements)
- (c) Chimney Sections
- (d) Floor Penetration (see chimney manufacturer's requirements)
- (e) Min. air space to combustibles (see chimney manufacturer's requirements – typically 2")
- (f) Connector – see "Chimney Connector" on the previous page.




Figure 4

### Drafting Performance

This appliance relies upon natural draft to operate. External forces, such as wind, barometric pressure, topography, or factors of the home (negative pressure from exhaust fans, chimneys, air infiltration, etc.), may adversely affect draft. Travis Industries can not be responsible for external forces leading to less than optimal performance.

### Chimney Termination Requirements

- Must have an approved cap (to prevent water from entering).
- Must not be located where it will become plugged by snow or other material.
- Must terminate at least 3' (914mm) above the roof and at least 2' (610mm) above any portion of the roof within 10' (3.04M) - see Figure 5.




Figure 5

### Outside Air Requirements

- Required for mobile homes & in certain localities (check with building officials).
- Must not be drawn from an enclosed space (garage, unventilated crawl space). May be drawn from ventilated crawl space (a) or exterior of home (d). Must have suitable rodent/debris screen and rain protection (hood).
- Requires the optional outside air kit (sku 99200139 – see (c) and (e) below), air boot (for legs), or pedestal (b).
- Air duct maximum length is 15' (4.57M) with a minimum cross section of 16 square inches (10404mm) or 6' (1.82M) with a minimum cross section of 7 square inches (4489mm).




Figure 6

## Alcove Installation Requirements

Whenever the stove is placed in a location where the ceiling height is less than 7' tall, it is considered an alcove installation. Because of the reduced height, the special installation requirements listed below must be met.

- Chimney connector and chimney must be one of the following types:

AMERI-TEC model DCC with model HS chimney  
 DURAVENT model DVL with DURATEC or DURA-PLUS chimney  
 GSW Super Chimney Twenty-One connected directly to appliance  
 I.C.C. Excel (2100-2 Can.) (103-HT USA) chimney with HP connector  
 METALFAB model DW connector with TG chimney  
 OLIVER MACLEOD PROVENT model PV connector with model 3103 chimney  
 SECURITY model DP connector with SECURITY model ASHT or S2100 chimney  
 SELKIRK METALBESTOS model DS connector with model SSII chimney  
 Standard Masonry Chimney with any one of the above listed connectors

**NOTE:** Reduced clearance connectors may not connect to the flue collar – an appliance adapter may be required.

- Alcoves are classified as combustible or non-combustible. Non-combustible alcoves must have walls and a ceiling that are 3 1/2" thick of a non-combustible material (brick, stone, or concrete - see Figure 7). This non-combustible material must be spaced and ventilated at least 1" off of all combustible materials (walls, ceiling, etc.) to allow air to move around the non-combustible walls and ceiling. All other alcoves are considered combustible. The clearances below must be met:

| Minimum Clearance<br>(See the Figure 7 below) |                          | Combustible Alcove |        | Non-Combustible Alcove     |        |
|-----------------------------------------------|--------------------------|--------------------|--------|----------------------------|--------|
| A                                             | Sidewall to stove        | 13"                | 331mm  | 6"                         | 153mm  |
| B                                             | Backwall to stove        | 9"                 | 229mm  | 2"                         | 51mm   |
| D                                             | Connector to sidewall    | 21.5"              | 547mm  | 14.5"                      | 369mm  |
| E                                             | Connector to backwall    | 11.5"              | 293mm  | 4.5"                       | 115mm  |
| G                                             | Maximum depth of alcove  | 48"                | 1220mm | 48"                        | 1220mm |
| H                                             | Minimum width of alcove  | 49.625"            | 1261mm | 35.625"                    | 905mm  |
| J                                             | Minimum height of alcove | 84"                | 2134mm | 6" (153mm) above stove top |        |





Figure 7

### Mobile Home Requirements

- Outside air must be installed - see "Outside Air Requirements" on page 12
- Chimney connector and chimney must be one of the following types:
  - AMERI-TEC model DCC with model HS chimney
  - DURAVENT model DVL with DURATEC or DURA-PLUS chimney
  - GSW Super Chimney Twenty-One connected directly to appliance
  - I.C.C. Excel (2100-2 Can.) (103-HT USA) chimney with HP connector
  - METALFAB model DW connector with TG chimney
  - OLIVER MACLEOD PROVENT model PV connector with model 3103 chimney
  - SECURITY model DP connector with SECURITY model ASHT or S2100 chimney
  - SELKIRK METALBESTOS model DS connector with model SSII chimney
  - Standard Masonry Chimney with any one of the above listed connectors
- NOTE: Reduced clearance connectors may not connect to the flue collar – an appliance adapter may be required.
- Stove placement must maintain the following clearances to combustibles (drywall, furniture, etc.)




Figure 8

| Minimum Clearance<br>(See the illustration above) |                         | Reduced Clearance<br>Connector |       |
|---------------------------------------------------|-------------------------|--------------------------------|-------|
| A                                                 | Sidewall to stove       | 13"                            | 331mm |
| B                                                 | Backwall to stove       | 9"                             | 229mm |
| C                                                 | Cornerwall to stove     | 7.5"                           | 191mm |
| D                                                 | Connector to sidewall   | 21.5"                          | 547mm |
| E                                                 | Connector to backwall   | 11.5"                          | 293mm |
| F                                                 | Connector to cornerwall | 16.5"                          | 420mm |

- If using offsets, use the connector clearance listed in Figure 9, **not the connector manufacturer's clearance.**
- The appliance must be secured to the floor (consult your building official). Secure the outside air boot to the floor and stove to insure the stove does not dislocate.
- Mobile home installations require a spark arrester at the chimney termination.
- The appliance must be grounded to the chassis of the mobile home (consult your building official).
- **WARNING:DO NOT INSTALL IN SLEEPING ROOM.**
- **CAUTION:THE STRUCTURAL INTEGRITY OF THE MOBILE HOME FLOOR, WALL, AND CEILING/ROOF MUST BE MAINTAINED.**




Figure 9

## Standard Ceiling with a Factory Built Chimney




Figure 10

## Cathedral Ceiling with a Factory Built Chimney




Figure 11

## Exterior Factory Built Chimney

### NOTE:

Exterior chimneys are subject to greater moisture and creosote accumulation due to the lower temperatures. An insulated chase will reduce these accumulations (the proper clearances to the chimney must be maintained).




Figure 12

## Hearth Stove Positive Connection

### NOTE:

Most factory-built chimney manufacturers make stainless steel chimney liners, either flexible or rigid. This provides a wide variety of installation options. Make sure to follow the manufacturer's instructions for installation and support.

NOTE: The entire fireplace and chimney must be clean, undamaged, and meet all local building codes (UBC, etc.). Damage must be repaired prior to installation. The chimney must be 15' to 33' tall.




Figure 13

## Hearth Stove Direct Connection

### NOTE:

This type of installation is not allowed in Canada.

### NOTE:

Direct connections require installation of an airtight, non-combustible block-off plate or damper adapter.

NOTE: The chimney must have a clay tile liner. If it does not, the installation must use a positive connection (full reline). The entire fireplace and chimney must be clean, undamaged, and meet all local building codes (UBC, etc.). Damage must be repaired prior to installation. The chimney must be 15' to 33' tall.




Figure 14

## Interior or Exterior Masonry Chimney

### NOTE:

This type of installation is not allowed in Canada.

### NOTE:

This type of installation requires a UBC approved masonry connector or a factory built (U.L. Listed) wall thimble.

NOTE: The chimney must have a clay tile liner. If it does not, the installation must use a positive connection (full reline). The entire fireplace and chimney must be clean, undamaged, and meet all local building codes (UBC, etc.). Damage must be repaired prior to installation. The chimney must be 15' to 33' tall.

See the section "Stove Placement Requirements" for minimum clearances required.

Chimney connector sections

See the section "Floor Protection Requirements"




Figure 15

**SAFETY NOTICE:**

Please read this entire manual before you install and use your new room heater. Failure to follow instructions may result in property damage, bodily injury, or even death. Contact local building or fire officials about restrictions and installation inspection requirements in your area.

**Planning The Installation**

We suggest that you have an authorized Travis Industries dealer install your fireplace insert. If you install the fireplace insert yourself, your authorized dealer should review your installation plans.



Check with local building officials for any permits required for installation of this fireplace insert and notify your insurance company before proceeding with installation.

**Preparation for Installation**

- Check for damage to the exterior of the fireplace insert (dents should be reported, scratches can be fixed by applying touch up paint).
- Check the interior of the firebox (replace cracked firebrick and make sure baffle is in place).



The fireplace insert can be lightened by removing the firebricks and baffle (pg 33) - replace before operation.

**Additional Accessories Needed for Installation**


- Door Shell (Black 99300195 Brass 99300196 or Pewter 99300197 - see 37)
- Surround Panels (see page 44)

**Installation Considerations**

| <u>Installation Type</u>                             | <u>Considerations</u>                                                                                                                                                                  |
|------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Insert with Positive Flue (Full Reline)<br>(Page 22) | <ul style="list-style-type: none"> <li>• Utilizes existing masonry or zero clearance fireplace</li> <li>• Provides best draft</li> <li>• Easiest to clean</li> </ul>                   |
| Insert with Direct Connect Flue<br>(Page 22)         | <ul style="list-style-type: none"> <li>• Utilizes existing masonry or zero clearance fireplace</li> <li>• Provides good draft</li> <li>• Requires fireplace block-off plate</li> </ul> |

## Fireplace Requirements

Figure 16 shows the minimum size requirements for the type of fireplace used.




| Minimum Fireplace Size                                                                 | Masonry Fireplace                                   | Z.C. (Metal) Fireplace                              |
|----------------------------------------------------------------------------------------|-----------------------------------------------------|-----------------------------------------------------|
| <b>a Height (front)</b>                                                                | 20.75"<br>528mm                                     | 20.75"<br>528mm                                     |
| <b>b Height (rear)</b>                                                                 | 20.75"<br>528mm                                     | 20.75"<br>528mm                                     |
| <b>c Width (front)</b>                                                                 | 23.625"<br>601mm                                    | 25.625"<br>651mm                                    |
| <b>d Width (rear)</b>                                                                  | 23.625"<br>601mm                                    | 25.625"<br>651mm                                    |
| <b>e Depth</b>                                                                         | 13.5"<br>343mm                                      | 14.5"<br>369mm                                      |
| <b>f Hearth Depth (includes insert depth on hearth plus required hearth extension)</b> | 19"<br>483mm (US)<br>-----<br>21"<br>534mm (Canada) | 19"<br>483mm (US)<br>-----<br>21"<br>534mm (Canada) |
| <b>g Hearth Width</b>                                                                  | 39.625"<br>1007mm                                   | 39.625"<br>1007mm                                   |
| <b>h Facing Width</b>                                                                  | 42.625"<br>1083mm                                   | 47.625"<br>1210mm                                   |
| <b>i Facing Height</b>                                                                 | 32"<br>813mm                                        | 32"<br>813mm                                        |
| <b>j Mantel Height</b>                                                                 | 35.5"<br>902mm                                      | 44"<br>1118mm                                       |

Figure 16


## Fireplace Altered Tag

Attach the "This fireplace has been altered..." plate to the fireplace (use two screws or other suitable method). You may wish to place it in a location where it will be covered by the surround panels.



### Insert Placement Requirements

- The insert must be placed so that no combustibles are within, or can swing within (e.g. drapes, doors), 36" of the front of the insert (Figure 17 "q").
- Insert and hearth must be installed on a level, secure floor
- The minimum clearances, facing, and hearth requirements in Figure 17 must be met. Follow the clearances for the type of fireplace being used – (masonry or zero-clearance-metal).



| Minimum Clearances                                            | Masonry Fireplace                                   | Z.C. (Metal) Fireplace                              |
|---------------------------------------------------------------|-----------------------------------------------------|-----------------------------------------------------|
| <b>k Sidewall</b>                                             | 13"<br>331mm                                        | 30"<br>762mm                                        |
| <b>l Side Facing (non-combustible)</b>                        | 9.5"<br>242mm                                       | 12"<br>305mm                                        |
| <b>m Top Facing (non-combustible)</b>                         | 12"<br>305mm                                        | 12"<br>305mm                                        |
| <b>n Mantel (combustible)</b>                                 | 15.5"<br>394mm                                      | 24"<br>610mm                                        |
| <b>o Front Hearth (does not include insert extension "x")</b> | 16"<br>407mm (US)<br>-----<br>18"<br>458mm (Canada) | 16"<br>407mm (US)<br>-----<br>18"<br>458mm (Canada) |
| <b>p Side Hearth</b>                                          | 8"<br>204mm                                         | 8"<br>204mm                                         |
| <b>q Front of Insert</b>                                      | 36"<br>915mm                                        | 36"<br>915mm                                        |
| <b>x Extension Onto Hearth</b>                                | 3"<br>77mm                                          | 3"<br>77mm                                          |

Figure 17

### Hearth Requirements

- Must extend 16" in front of the insert and 8" on both sides (min. 19" deep by 39-5/8" wide)
- Must be non-combustible and at least .018" thick (26 gauge)

### Masonry Fireplace Requirements

- Chimney must have a clay tile liner or a stainless steel liner (positive connection).
- Entire fireplace, including chimney, must be clean and undamaged. Any damage must be repaired prior to installation of the insert.
- Chimney height: 15' minimum; 33' maximum.
- Entire fireplace, including chimney, must meet local building requirements.

## Zero-Clearance (Metal) Fireplace Requirements

- Must utilize a positive (full reline) or direct connection (block-off plate)
- Must be manufactured by one of the following manufacturers:
  - Marco • Majestic • Heatilator • Preway • Tempco • Superior
  - Heat N Glo • Lennox • Martin • Monesson
- Entire fireplace, including chimney, must be clean and undamaged. Any damage must be repaired prior to installation of the insert
- Entire fireplace, including chimney, must meet local building requirements
- Chimney height: 15' minimum; 33' maximum. Minimum cross section: 28.65 square inches
- The damper ("A") and grate ("B") must be removed (see Figure 18). The smoke shelf ("C"), internal baffles ("D"), screen ("E"), and metal or glass doors ("F") may be removed (if applicable). The masonry lining ("G"), insulation ("H"), and any structured rigid frame members (metal sides, floor, door frame, face of the fireplace, etc. – "I") may not be removed or altered




Figure 18

## Drafting Performance

This appliance relies upon natural draft to operate. External forces, such as wind, barometric pressure, topography, or factors of the home (negative pressure from exhaust fans, chimneys, air infiltration, etc.), may adversely affect draft. Travis Industries can not be responsible for external forces leading to less than optimal performance.

## Leveling Bolt Installation

Two leveling bolts are included to level the insert if the fireplace has a stepped-up hearth. To install, raise the rear of the insert and insert the leveling bolts into the holes in the rear corners of the insert. Adjust the bolts until they extend the same height as the hearth (see Figure 19). After the insert is installed, fine-tune the leveling bolts to level the insert.




Figure 19

### Insert with Positive Connection

**REQUIRED IN CANADA.**




Figure 20

### Insert with Direct Connection (Masonry Fireplace)

**NOT ALLOWED IN CANADA.**

A block-off plate or other non-combustible sealing device (e.g. damper adapter) is required. It must seal the chimney to insure smoke does not enter the home while providing the chimney system with sufficient draft.




Figure 21

## Safety Notice



If this appliance is not properly installed, a house fire may result. For your safety, follow the installation directions. Contact local building or fire officials about restrictions and installation inspection requirements in your area.



Read and follow all of the warnings on pages 4 and 5 of this manual.

## Before Your First Fire

Verify the Installation

Before starting the stove, verify that the stove is properly installed and all of the requirements in this manual have been followed.




Keep all flammable materials 36" away from the front of the stove (drapes, furniture, clothing, etc.).

## Curing the Paint

This heater uses a heat-activated paint that will emit some fumes while starting the first fire. Open doors and windows to the room to vent these fumes. This typically lasts two to four hours. You may also notice oil burning off of the interior of the heater. This rust-stopping agent will soon dissipate.

**Door Gasket** - The door gasket might adhere to the paint on the front of the heater. Leave the door slightly ajar for the first fire and be careful when opening the door after the first fire.

2 to 4 hours



## Over-Firing the Stove


This stove was designed to operate at a high temperature. But due to differences in vent configuration, fuel, and draft, this appliance can be operated at an excessive temperature. If the stove top or other area starts to glow red, you are over-firing the stove. Shut the air control down to low and allow the stove to cool before proceeding.




Over-firing may lead to damage of plated surfaces. If you are uncertain of over-firing conditions, we suggest placing a stove thermometer (e.g. Rutland® Model 710) directly over the door on the stove top - temperatures exceeding 800° are generally considered over-firing and will void the warranty.

## Opening the Door

Rotate  
the door  
handle.



Swing  
the door  
open.



The door becomes hot during use. Use a glove to open the door if the handle is hot.




To prevent smoke from entering the room, open the air control before opening the door. You can also open the door a small amount and let air enter the firebox.

## Starting a Fire

Since the dawn of time man has debated the best way to start a fire. Some use the boy-scout "tee-pee", some prefer the "tic-tac-toe" stack. Either way, review the hints and warnings below to ensure proper fire starting.

- Make sure the air control is pushed in. If additional air is needed, open the doors 1/4" during the first five minutes of start-up.



**Never** use gasoline, gasoline-type lantern fuel, kerosene, charcoal lighter fluid, or similar liquids to start or "freshen up" a fire in this stove. Keep all such liquids well away from the stove while it is in use.



DO NOT USE CHEMICALS OR FLUIDS TO START THE FIRE. DO NOT BURN GARBAGE OR FLAMMABLE FLUIDS SUCH AS GASOLINE, NAPHTHA OR ENGINE OIL. Do not place such fuel within space heater installation clearances or within the space required for charging and ash removal.



If using a fire-starter, use only products specifically designed for stoves - follow the manufacturer's instructions carefully.




HOT WHILE IN OPERATION. KEEP CHILDREN, CLOTHING AND FURNITURE AWAY. CONTACT MAY CAUSE SKIN BURNS.



If the smoke does not pass up the chimney, ball up one sheet of newspaper, place it in the center of the firebox and light it. This should start the chimney drafting (this eliminates "cold air blockage").




Use plenty of kindling to ensure the stove reaches a proper temperature. Once the kindling is burning rapidly, place a few larger pieces of wood onto the fire.



## Adjusting the Burn Rate

Use the air control slider to control the burn rate of the stove. See the illustration below for details.

Use the air control to change the burn rate.



### Approximate Air Control Settings

|                  |                                |
|------------------|--------------------------------|
| Overnight Burn   | Fully out to 9/32" open        |
| Medium Burn      | 9/32" to 5/16" open            |
| Medium High Burn | 5/16" to 7/16" open            |
| High Burn        | 7/16" open top pushed fully in |



The air control becomes hot during operation - use gloves or a tool to prevent burns.



The air control may take several minutes to influence the burn rate. When making adjustments, you may wish to let the stove burn for 10 minutes to gauge performance.

## Ash Removal




Ashes should be placed in a metal container with a tight fitting lid. The closed container of ashes should be placed on a noncombustible floor or on the ground, away from all combustible materials, pending final disposal. If the ashes are disposed of by burial in soil or otherwise locally dispersed, they should be retained in the closed container until all cinders have thoroughly cooled.

### Optional Blower Operation

The blower will turn on once the stove is up to temperature. This is typically 15 to 30 minutes after starting the fire. Follow the directions below to alter the blower speed.


#### **OFF**

Turn the dial all the way counter-clockwise until it clicks off.




#### **HIGH**

The high position is all the way counter-clockwise, **without** clicking off.



#### **LOW**

Turn the dial all the way clockwise.



The blower may be used to affect heat output (i.e.: to reduce heat output, turn the blower down).



Route the power cord in a location where it will not come in contact with the appliance or become hot.

### Re-Loading the Stove

Follow the directions below to minimize smoke spillage while re-loading the stove.

- 1 Open the air control all the way (push it in).
- 2 Open the door slightly. Let the airflow inside the firebox to stabilize before opening the doors fully.
- 3 Load wood onto the fire.

### Overnight Burn

This stove is large enough to accommodate burn times up to eight hours. Follow the steps below to achieve an overnight burn.

- 1 Move the air control to high burn and let the stove become hot (burn for approximately 15 minutes).
- 2 Load as much wood as possible. Use large pieces if possible.
- 3 Let the stove burn on high for 15 minutes to keep the stove hot, then turn the air control to low.
- 4 In the morning the stove should still be hot, with embers in the coal bed. Stir the coals and load small pieces of wood to re-ignite the fire, if desired.



Differences in chimney height and draft may lower overall burn times.

### Normal Operating Sounds

#### **Creaks and Clicks:**


The 3/16" and 1/4" steel may creak or click when the stove heats up and cools down - this is normal.

#### **Blower Sounds:**

The blower will make a slight "hum" as it pushes air through the stove.

#### **Hint:**

Make sure the leveling bolts on legs are extended - preventing the hearth from amplifying any vibrations.




## Hints for Burning

- Get the appliance hot before adjusting to low burn
- Use smaller pieces of wood during start-up and high burns to increase temperature
- Use larger pieces of wood for overnight or sustained burns
- Stack the wood tightly together to establish a longer burn
- Leave a bed of ashes (1/2" deep) to allow for longer burns
- Be considerate of neighbors & the environment: burn dry wood only
- Burn small, intense fires instead of large, slow burning fires when possible
- Learn your appliance's operating characteristics to obtain optimum performance

## Selecting Wood


- Dry Wood is Key
- Dry wood burns hot, emits less smoke and creates less creosote.
- Testing Wood Moisture
- Split wood stored in a dry area will be fully dry within a year. This insures dry wood. If purchasing wood for immediate use, test the wood with a moisture meter. Some experienced wood burners can measure wood moisture by knocking pieces together and listening for a clear "knock" and not a "thud".



## Why Dry Wood is Key

Wet wood, when burned, must release water stored within the wood. This cools the fire, creates creosote, and hampers a complete burn. Ask any experienced wood burner and he or she will agree: dry wood is crucial to good performance.

## Wood Cutting and Storage



**Troubleshooting**

| <b>Problem</b>                                 | <b>Possible Cause</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Smoke Enters Room During Start-Up</b>       | <ul style="list-style-type: none"> <li>• Open the air control (pg. 25).</li> <li>• Cold Air Blockage - burn a piece of newspaper to establish a draft.</li> <li>• If the flame is not getting enough air, a small crack in the door is all that is needed.</li> </ul>                                                                                                                                                                                                                                                                                                |
| <b>Kindling Does Not Start - Fire Smolders</b> | <ul style="list-style-type: none"> <li>• Open the air control (pg. 25).</li> <li>• Not enough starter paper - use additional newspaper if necessary.</li> <li>• If the flame is not getting enough air, a small crack in the door is all that is needed.</li> </ul>                                                                                                                                                                                                                                                                                                  |
| <b>Smoke Enters Room While Re-Loading</b>      | <ul style="list-style-type: none"> <li>• Open the air control before opening the door (pg. 25).</li> <li>• Let the air stabilize before fully opening the door. Then open the door approximately 1 inch. Let air go into the firebox for a few seconds. Once the smoke appears to be flowing up the chimney consistently, open the door.</li> <li>• Insufficient Draft - Chimney height and outside conditions can negatively affect draft. In these cases a small amount of smoke may enter the home. Adding more pipe or a draft-inducing cap may help.</li> </ul> |
| <b>Stove Does Not Burn Hot Enough</b>          | <ul style="list-style-type: none"> <li>• Wood is Wet - see the section "Selecting Wood" on page 27 for details on wood.</li> <li>• Make sure the air control is all the way open. Slide the control back and forth to insure the control is not stuck.</li> <li>• Insufficient Draft - Chimney height and outside conditions can negatively affect draft. In these cases the fire may burn slowly. Adding more pipe or a draft-inducing cap may help.</li> </ul>                                                                                                     |
| <b>Blower Does Not Run</b>                     | <ul style="list-style-type: none"> <li>• Stove is Not Up to Temperature - This is normal. The blower will come on when the stove is hot - usually 15 to 30 minutes.</li> <li>• Electricity is Cut to the Blower - Check the household breaker or fuse to make sure it is operable.</li> </ul>                                                                                                                                                                                                                                                                        |
| <b>Stove Does Not Burn Long Enough</b>         | <ul style="list-style-type: none"> <li>• Depending upon wood, draft, and other factors, the burn time may be shorter than stated. Make sure the doors are sealing and not allowing air into the firebox - See the section "Door and Glass Inspection" on page 30 for details.</li> <li>• Check the ash bed for coals. Often, coals are still glowing under a slight bed of flyash. By raking these into a pile you can re-start your stove quickly.</li> </ul>                                                                                                       |



Failure to properly maintain and inspect your appliance may reduce the performance and life of the appliance, void your warranty, and create a fire hazard.



Establish a routine for the fuel, wood burner and firing technique. Check daily for creosote build-up until experience shows how often you need to clean to be safe. Be aware that the hotter the fire the less creosote is deposited, and weekly cleaning may be necessary in mild weather even though monthly cleaning may be enough in the coldest months. Contact your local municipal or provincial fire authority for information on how to handle a chimney fire. Have a clearly understood plan to handle a chimney fire.

## Daily Maintenance (while stove is in use)

### Remove Ash (if necessary)

- Ash removal is **not** required once it builds up. 1/2" to 1" of ash may be desirable because it slows the burn rate. Generally, remove ash once it has built up over 1". Follow the directions below to remove ash.

- Let the stove cool completely (at least two hours after the last coal has extinguished).
- Place a cloth or cardboard protector over the hearth to catch ash and protect against scratching.
- Open the doors and scoop the ash into a metal container with a tight fitting lid. The closed container of ashes should be placed on a noncombustible floor or on the ground, away from all combustible materials, pending final disposal.



Improperly disposed ashes lead to fires. Hot ashes placed in cardboard boxes, dumped in back yards, or stored in garages, are recipes for disaster.



Wood-burning stoves are inherently dirty. During cleaning have a vacuum ready to catch spilled ash (make sure ash is entirely extinguished).



There are vacuum cleaners specifically made to remove ash (even if the ash is warm). Contact your dealer for details.


### Clean the Glass (if necessary)

This appliance has an airwash to keep the glass clean. However, burning un-seasoned wood or burning on lower burn rates leads to dirtier glass (especially on the sides). Clean the glass by following the directions below. Do not clean glass with abrasive cleaners.

Allow the stove to fully cool. Apply glass cleaner or soapy water to the inside of the glass. Wipe with newspaper or a paper towel.

#### For Stubborn Creosote:

Dip newspaper or a paper towel in cool ashes and wipe it on the glass. The ash acts as a light abrasive.



The glass will develop a very slight haze over time. This is normal and will not affect viewing of the fire.

### Monthly Maintenance (while appliance is in use)




Make sure the appliance has fully cooled prior to conducting service.

#### Door and Glass Inspection


The door must form an air-tight seal to the firebox for the stove to work correctly. Inspect the door gasket to make sure it forms an air-tight seal to the firebox.



The door can be lifted off the hinges if extensive repairs are conducted.



The door latch should pull the door against the face of the stove (but not so tight as to not allow full handle rotation). If the latch requires adjustment, follow the directions below.



#### Creosote - Formation and Need for Removal

When wood is burned slowly, it produces tar and other organic vapors, which combine with expelled moisture to form creosote. The creosote vapors condense in the relatively cool chimney flue of a slow-burning fire. As a result, creosote residue accumulates on the flue lining. When ignited, this creosote makes an extremely hot fire. The chimney and chimney connector should be inspected at least once every two months during the heating season to determine if a creosote buildup has occurred. If creosote has accumulated, it should be removed to reduce the risk of a chimney fire.



If you are not certain of creosote inspection, contact your dealer or local chimney sweep for a full inspection. Excess creosote buildup may cause a chimney fire, that may result in property damage, injury, or death.



Operating this appliance continually at a low burn rate (air starvation) or using green (un-seasoned wood) will increase the formation of creosote.


## Yearly Maintenance



Make sure the appliance has fully cooled prior to conducting service.


### Touch Up Paint

Included with the owner's pack of this appliance is a can of Stove-Brite® paint. To touch up nicks or dulled paint, apply the paint while the appliance is cool. Sand rusted or damaged areas before preparation (use 120 grit sandpaper). Clean and dry the area to prepare the surface. Wait at least one hour before starting the appliance. The touched up area will appear darker than the surrounding paint until it cures from heat. Curing will give off some fumes while curing – open windows to ventilate.



### Cleaning the Air Duct and Blower (if applicable)

Use a vacuum to clean the air ducts (channels). This prevents dust from burning and creating odors. The optional blower should be vacuumed every year to remove any buildup of dust, lint, etc.



Use a vacuum cleaner to remove any buildup on the screens of the blower.

### Firebrick and Baffle Inspection

Use the illustration on page 33 as a reference for checking the following items. Make sure the appliance is cool before proceeding.


Baffle Firebricks - check the bricks along the ceiling of the firebox to make sure they are intact and have no gaps between them. Slide the bricks to eliminate any gaps.

Baffle Supports - make sure the front and back baffle supports in are place and not degraded. Slight scaling or rusting of the metal is normal.

Secondary Air Tubes - Check the two air tubes and collars to make sure they are intact and not severely deteriorated. Slight scaling or rusting of the metal is normal. Make sure the push pins hold the air tubes in place.

Floor and Wall Firebricks - replace any severely damaged firebrick along the side or floor of the firebox.

## Door Parts



| ID # | Description                                                                          | Qty | Part #                              | ID # | Description                                         | Qty    | Part #                             |
|------|--------------------------------------------------------------------------------------|-----|-------------------------------------|------|-----------------------------------------------------|--------|------------------------------------|
| 1    | Door Shell - Black<br>Door Shell - Brass<br>Door Shell - Pewter                      | 1   | 230-00570<br>230-00572<br>230-00568 | 2    | Glass (15-3/8" x 8-7/8")                            | 1      | 173-01002                          |
| 3    | Glass Gasket                                                                         | 1   | 224-11086                           | 4    | Door Retainer (w gasket)                            | 1      | 224-23020                          |
| 5    | Gasket Cement                                                                        | 1   | 99900409                            | 6    | Door Gasket                                         | 1      | 99900407                           |
| 7    | Door Handle Asbly - Black<br>Door Handle Asbly - Brass<br>Door Handle Asbly - Pewter | 1   | 224-14042<br>99900410<br>224-14052  | 8    | Spring - Black<br>Spring - Brass<br>Spring - Pewter | 1      | 100-14122<br>99300100<br>100-04103 |
| 9    | Washers                                                                              | 2   | 100-03501                           | 10   | Cam                                                 | 1      | 99900417                           |
| 11   | Nut, Brass                                                                           | 1   | 101-00007                           | 12   | Glass Clips - Top<br>Glass Clip - Bottom            | 2<br>1 | 224-230022<br>224-230021           |
| 13   | #8-32 3/8" Type F Screw                                                              | 8   | 225-20039                           | 14   | Set Screw                                           | 2      | 225-20038                          |

### Replacing the Glass



The glass must not contact the door retainer or glass clips directly. The glass gasket and glass clip gaskets insulate the glass to prevent cracking. Do not over-tighten the glass clips.

See "Door Shell Installation" (pg. 37) for details on removing the door handle and shell. **NOTE:** The glass gasket is placed in the groove along the inside perimeter of the door retainer. Make sure the glass clip screws are all fully tightened - they must be flush with the door retainer for the door shell to install.


### Replacing the Door Gasket

The door gasket inserts into the outer groove of the door retainer. Stove gasket cement holds it in place. Before installing, remove any residual cement. Lay the gasket in place (start at the lower left corner) and cut off any excess gasket (do not stretch the gasket. The cement fully cures with heat from the stove. You may need to open and close the door repeatedly to get the gasket to seat fully.

### Replacing the Door Handle

See the illustration above for a component list (see pg. 30 for details on adjusting the door).

## Firebox Parts



| ID # | Description              | Qty | Part #                 |  | ID # | Description              | Qty | Part #    |
|------|--------------------------|-----|------------------------|--|------|--------------------------|-----|-----------|
| 1    | Baffle Support "S" Bar   | 1   | 99900294               |  | 2    | Air Tube with Sleeve     | 3   | 98900232  |
| 3    | Air Tube Roll Pins       | 6   | 98900357               |  | 4    | Air Tube Retainer Sleeve | 3   | 98900356  |
| 5    | Brick - 9" x 4.5" un-cut | 16  | 98900102<br>(qty of 9) |  | 6    | Brick, Cut - 9" x 2.5"   | 3   | 251-00019 |
| 7    | Brick, Cut - 9" x 1.375" | 2   | 251-00018              |  |      |                          |     |           |

### Floor and Side Firebrick Removal & Replacement

**Do not pry firebrick - they chip and crack easily.** Remove the floor firebricks first. The side firebrick are removed later because they are pinned in place by the floor firebrick. Clean the firebox prior to replacing the firebrick.

### ***Baffle Removal & Replacement***




The baffle is held up by the front air tube. Make sure to support the baffle after removing the air tubes.

- Lift the four baffle firebricks then lift the baffle deflector up and over its resting position.
- Slide the bricks forward and tilt them downwards to remove.

### ***Air Tube Removal & Replacement***



All three air tubes are identical.



# Limited 7 Year Warranty

35

To register your TRAVIS INDUSTRIES, INC. 7 Year Warranty, complete the enclosed warranty card and mail it within **ten (10)** days of the appliance purchase date to: TRAVIS INDUSTRIES, INC., 4800 Harbour Pointe Blvd. SW, Mukilteo, WA 98275. TRAVIS INDUSTRIES, INC. warrants this gas appliance (appliance is defined as the equipment manufactured by Travis Industries, Inc.) to be defect-free in material and workmanship to the original purchaser from the date of purchase as follows:

Check with your dealer in advance for any costs to you when arranging a warranty call.  
Mileage or service charges are not covered by this warranty. This charge can vary from store to store.

## Years 1 & 2 - COVERAGE: PARTS & LABOR

### Firebox Assembly:

Firebox, Baffle Supports, Air Tubes, Air Channels, Convection Chamber

### Door Assembly:

Solid Brass or Cast Door, Latch Assembly, Glass Retainers

### Plated Finish

Plated Door, Legs, etc... See "Conditions & Exclusions" # 9 below.

### Air Control Assembly

Slider Plate, Pressure Plate

**Exclusions:** Paint, Gasketing

### Ceramic Glass

Glass (breakage from thermal shock)

### Firebrick

Breakage from thermal shock

### Accessories

Legs, Pedestal, Panels, Blower

### Re-Installation Allowance

In cases where heater must be removed from home for repairs, a partial cost of re-installation is covered (pre-authorization required)

### One-Way Freight Allowance

One-way freight allowance on pre-authorized repair done at factory is covered.

## Years 3 Through 5 - COVERAGE: PARTS & LABOR

### Firebox Assembly:

Firebox, Baffle Supports, Air Tubes, Air Channels, Convection Chamber

### Air Control Assembly

Slider Plate, Pressure Plate

**Exclusions:** Paint, Gasketing, Plated Finish, Accessories (Legs, Pedestal, Panels, Blower), Glass, Firebrick, Re-Installation Allowance

### Door Assembly:

Solid Brass or Cast Door, Latch Assembly, Glass Retainers

### One-Way Freight Allowance

One-way freight allowance on pre-authorized repair done at factory is covered.

## Years 6 & 7 - COVERAGE: PARTS ONLY

### Firebox Assembly:

Firebox, Baffle Supports, Air Tubes, Air Channels, Convection Chamber

### Door Assembly:

Solid Brass or Cast Door, Latch Assembly, Glass Retainers

### Air Control Assembly

Slider Plate, Pressure Plate

**Exclusions:** Paint, Gasketing, Plated Finish, Accessories (Legs, Pedestal, Panels, Blower), Glass, Firebrick, Re-Installation Allowance, One-Way Freight Allowance, Labor

## CONDITIONS & EXCLUSIONS

1. This new appliance must be installed by a qualified installer. It must be installed, operated, and maintained at all times in accordance with the instructions in the Owner's Manual. Any alteration, willful abuse, accident, neglect, or misuse of the product shall nullify this warranty.
2. This warranty is nontransferable, and is made to the ORIGINAL purchaser, provided that the purchase was made through an authorized Travis dealer.
3. Discoloration and some minor expansion, contraction, or movement of certain parts and resulting noise, is normal and not a defect and, therefore, not covered under warranty. Over-firing (operation where the steel may glow red) of this appliance can cause serious damage and will nullify this warranty.
4. The warranty, as outlined within this document, does not apply to the chimney components or other Non-Travis accessories used in conjunction with the installation of this product. If in doubt as to the extent of this warranty, contact your authorized Travis retailer before installation.
5. Travis Industries will not be responsible for inadequate performance caused by environmental conditions such as nearby trees, buildings, roof tops, wind, hills or mountains or negative pressure or other influences from mechanical systems such as furnaces, fans, clothes dryers, etc.
6. This Warranty is void if:
  - a. The unit has been operated in atmospheres contaminated by chlorine, fluorine or other damaging chemicals.
  - b. The unit is subject to submersion in water or prolonged periods of dampness or condensation.
  - c. Any damage to the unit, combustion chamber, heat exchanger or other components due to water, or weather damage which is the result of, but not limited to, improper chimney/venting installation.
7. Exclusions to this 7 Year Warranty include: injury, loss of use, damage, failure to function due to accident, negligence, misuse, improper installation, alteration or adjustment of the manufacturer's settings of components, lack of proper and regular maintenance, damage incurred while the appliance is in transit, alteration, or act of God.
8. This 7 Year warranty excludes damage caused by normal wear and tear, such as paint discoloration or chipping, worn or torn gasketing, chipped or cracked firebrick, etc. Also excluded is damage to the unit caused by abuse, improper installation, modification of the unit, or the use of fuel other than that for which the unit is configured (use cord wood only).
9. Damage to brass or plated surfaces caused by fingerprints, scratches, melted items, or other external sources left on the surfaces from the use of abrasive cleaners is not covered in this warranty. Damage to the surfaces from over-firing (operation where the steel may glow red) is not covered in this warranty.
10. TRAVIS INDUSTRIES, INC. is free of liability for any damages caused by the appliance, as well as inconvenience expenses and materials. Incidental or consequential damages are not covered by this warranty. In some states, the exclusion of incidental or consequential damage may not apply.
11. This warranty does not cover any loss or damage incurred by the use or removal of any component or apparatus to or from the Travis appliance without the express written permission of TRAVIS INDUSTRIES, INC. and bearing a TRAVIS INDUSTRIES, INC. label of approval.
12. Any statement or representation of Travis products and their performance contained in Travis advertising, packaging literature, or printed material is not part of this 7 year warranty.
13. This warranty is automatically voided if the appliance's serial number has been removed or altered in any way. If the appliance is used for commercial purposes, it is excluded from this warranty.
14. No dealer, distributor, or similar person has the authority to represent or warrant Travis products beyond the terms contained within this warranty. TRAVIS INDUSTRIES, INC. assumes no liability for such warranties or representations.
15. Travis Industries will not cover the cost of the removal or re-installation of hearths, facing, mantels, venting or other components.
16. If for any reason any section of this warranty is declared invalid, the balance of the warranty remains in effect and all other clauses shall remain in effect.
17. This 7 year warranty is the only warranty supplied by Travis Industries, Inc., the manufacturer of the appliance. All other warranties, whether express or implied, are hereby expressly disclaimed and purchaser's recourse is expressly limited to the warranties set forth herein.

## IF WARRANTY SERVICE IS NEEDED:

1. If you discover a problem that you believe is covered by this warranty, you **MUST REPORT** it to your Travis dealer **WITHIN 30 DAYS**, giving them proof of purchase, the purchase date, and the model name and serial number.
2. Travis Industries has the option of either repairing or replacing the defective component.
3. If your dealer is unable to repair your appliance's defect, he may process a warranty claim through TRAVIS INDUSTRIES, INC., including the name of the dealership where you purchased the appliance, a copy of your receipt showing the date of the appliance's purchase, and the serial number on your appliance. At that time, you may be asked to ship your appliance, freight charges prepaid, to TRAVIS INDUSTRIES, INC. TRAVIS INDUSTRIES, INC., at its option, will repair or replace, free of charge, your appliance if it is found to be defective in material or workmanship within the time frame stated within this 7 year warranty. TRAVIS INDUSTRIES, INC. will return your appliance, freight charges (years 1 to 5) prepaid by TRAVIS INDUSTRIES, INC., to your regional distributor, or dealership.
4. Check with your dealer in advance for any costs to you when arranging a warranty call. Mileage or service charges are not covered by this warranty. This charge can vary from store to store.

## Listing Label

Listed By **O-T-L** Beaverton  
Oregon USA  
OMNI-Test Laboratories, Inc.  
REPORT #028-S-47-4

**DO NOT REMOVE THIS LABEL**  
CONTACT LOCAL BUILDING OR FIRE OFFICIALS ABOUT  
INSTALLATION AND RESTRICTIONS IN YOUR AREA.  
ROOM HEATER SOLID FUEL TYPE APPLIANCE ALSO FOR USE IN MOBILE HOMES  
SUITABLE FOR USE IN FACTORY-BUILT (Z.C.) FIREPLACES AND MASONRY FIREPLACES.



MODEL:  
**ANSWER (ANSWER-NT)**

TESTED TO UL 1482 AND APPLICABLE SECTIONS OF UL 127, 737 AND 907.  
FOR USE WITH SOLID WOOD FUEL ONLY

SERIAL  
NUMBER

**PREVENT HOUSE FIRES** - Install and use only in accordance with the manufacturer's installation and operating instructions. Contact your local building or fire officials about restrictions and installation inspection in your area. Refer to local building codes and manufacturer's instructions for precautions required for passing a chimney through a combustible wall or ceiling. Do not run a chimney connector through a combustible wall or ceiling. Do not connect this unit to a chimney flue serving another appliance. Clearances may be reduced by methods specified in NFPA 211, listed wall shields, pipe shields, or other means approved by local building or fire officials. Inspect and clean chimney frequently, under certain conditions of use creosote build up may occur rapidly. Do not overfire. If heater glows, you are overfiring. Maintain 36" front clearances to all furnishings and other combustible materials. Do not use grate or elevate fire, build wood fire directly on hearth. Operate only with door closed.

**OPTIONAL EQUIPMENT:** Front or rear blower (electrical rating: 115V, 60 Hz., 1.8 Amps)  
Replace glass only with LOPI supplied NEOCERAM ceramic glass (6mm).  
Do not route power cord under or in front of appliance.

#### FREESTANDING INSTALLATION

**STANDARD RESIDENTIAL FREESTANDING INSTALLATIONS REQUIRE:** 6" diameter, minimum 24 MSG black or 25 MSG blue steel connector, with listed UL-103 HT factory-built chimney, suitable for use with solid fuels or masonry chimney. Pedestal or legs are required.

**ALCOVE INSTALLATIONS REQUIRE:** One of the Listed doublewall connectors listed below. Pedestal or legs are required. Maximum alcove depth 48", minimum alcove height 84".


**MOBILE HOME AND REDUCED CLEARANCE INSTALLATIONS REQUIRE:** One of the Listed doublewall connectors listed below. In addition, mobile home installations require outside air - use the Lopi Answer optional pedestal or outside air boot. Pedestal or legs are required.

- DURAVENT model DVL with DURA-PLUS chimney
- AMERI-TEC model DCC with model HS chimney
- SECURITY model DP with SECURITY model ASHT or S2100 chimney
- GSW model Super Chimney Twenty-One connected directly to appliance
- SELKIRK METALBESTOS model DS connector with model SSII chimney
- DURAVENT Model DVL with DURA-TECH chimney

| CLEARANCES AND FLOOR PROTECTION REQUIREMENTS: | STANDARD RESIDENTIAL INSTALLATION (SINGLEWALL CONNECTOR) | MOBILE HOME, ALCOVE AND REDUCED CLEARANCE INSTALLATIONS (REQUIRES DOUBLE WALL CONNECTOR) |
|-----------------------------------------------|----------------------------------------------------------|------------------------------------------------------------------------------------------|
| A. SIDEWALL TO UNIT                           | 18"                                                      | 13"                                                                                      |
| B. BACKWALL TO UNIT                           | 16.5"                                                    | 9"                                                                                       |
| C. CORNERWALL TO UNIT                         | 10"                                                      | 7.5"                                                                                     |
| D. SIDEWALL TO CONNECTOR                      | 27"                                                      | 21.5"                                                                                    |
| E. BACKWALL TO CONNECTOR                      | 19.5"                                                    | 11.5"                                                                                    |
| F. CORNERWALL TO CONNECTOR                    | 19.5"                                                    | 16.5"                                                                                    |


U.S. ENVIRONMENTAL PROTECTION AGENCY  
Certified to comply with July 1990 particulate  
emission standards.

| DATE OF MANUFACTURE |      |      | 2004 | 2005 | 2006 |
|---------------------|------|------|------|------|------|
| Jan.                | Feb. | Mar. | Apr. | May  | June |
| July                | Aug. | Sep. | Oct. | Nov. | Dec. |



Manufactured By **Travis Industries, Inc.**  
4800 Harbour Pointe Blvd. SW Mukilteo,

#### LISTED FIREPLACE INSERT FOR INSTALLATION INTO A FACTORY-BUILT (Z.C.) FIREPLACE OR MASONRY FIREPLACE



| Minimum Clearance to Combustibles and Hearth Requirements | Masonry Fireplace Installations | Factory-Built (Z.C.) Fireplace Installations |
|-----------------------------------------------------------|---------------------------------|----------------------------------------------|
| A.                                                        | 13"                             | 30"                                          |
| B.                                                        | 9.5"                            | 12"                                          |
| C.                                                        | 12"                             | 12"                                          |
| With Shield                                               | N/A                             | N/A                                          |
| D.                                                        | 15.5"                           | 24"                                          |
| With Shield                                               | N/A                             | N/A                                          |
| Hearth Extension Front                                    | 16"                             | 16"                                          |
| Hearth Extension to Sides                                 | 8"                              | 8"                                           |

Masonry fireplace installation requirements, install with facing shroud plates, do not remove firebrick or mortar from masonry fireplace, install with or without a direct flue connection.


Factory-Built (Z.C.) Fireplace installations require a minimum 24" starter section directly connected to the fireplace chimney or a full re-line. Factory-Built (Z.C.) Fireplace chimney must have a minimum cross-sectional area of 28.85". The Factory-Built (Z.C.) Fireplace damper and control must be removed, or secured in the open position. For minimum Factory-Built (Z.C.) Fireplace firebox size, see manufacturer's installation instructions. Factory-Built (Z.C.) Fireplace floor protection must be 3/8" minimum non-combustible material or equivalent, extending 16" in front of insert and 8" to both sides. A metal deflector plate must be installed if the flue collar is not completely behind the lintel plate of the Factory-Built (Z.C.) Fireplace openings.

0240 (IGN)


## Door Shell Installation

Part Numbers: Black # 99300195, Brass # 9930096, Pewter # 99300197

1. Remove the door retainer shipping latch following the directions below.



2. Place the door shell face down on a non-scratching surface.
3. Remove and discard the two set screws pre-installed on the bottom of the door shell (if applicable).




**Nickel (Cast Iron) Doors Only**


Use a socket-head wrench with 5/16" socket to pre-thread the holes 6 revolutions. If you pre-thread more revolutions, it may bottom out and break the head off the screw. Remove and retain the screws. See the photos below.





4. Place the door retainer into the door shell as shown below.



Make sure the holes in the retainer line up with the holes on the shell then use a 5/16" nutdriver to secure the shell with the two screws. Tighten until the door shell is snug against the retainer (do not over-tighten).



5. Attach the door handle following the directions to the right.
6. Replace the door on the hinges and latch the door.
7. Attach the ashlip trim following the directions below.





Slide the ashlip trim into place then tighten the three set screws on the bottom of the ashlip to secure.

### ***Stove Leg Installation***

Part Numbers: Brass # 99200500, Cast Black # 99200800, Sculptured Steel # 99200105

- Raise the stove 8" (use lumber). Attach each leg following the instructions below.

Attach each leg to the stove by inserting a bolt and washer through the hole or slot in the leg and into the threaded hole on the stove.



9/16" Socket Wrench


These rubber-tipped bolts are for leveling the stove. Make sure they contact the floor. Do not adjust with weight on the legs, the rubber tips may tear.

## Pedestal (Part # 99200106)



If using outside air with the pedestal, follow the directions below under "Using Outside Air with the Pedestal" prior to installing the pedestal.

Use a 9/16" wrench to attach the two pedestal bolts to the bottom of the stove.




### Using Outside Air with the Pedestal

Before installing, check the section "Outside Air Requirements" 12 for installation concerns.

1. Determine the location of the outside air hole penetrating the floor (& hearth). The illustration above details the size of pedestal and its location in relation to the stove. The hole may be cut anywhere underneath the pedestal, as long as it is not within 2" of the outside perimeter of the pedestal, is at least 16 square inches in area, and does not interfere with structural members of the home. Place the rodent screen over the hole (above or below) and secure with staples.
2. Attach the stove to the pedestal with the included bolts. Tuck the included insulation underneath the side edges of pedestal to seal off any air from entering underneath the pedestal.
3. Install the cover plate following the directions below (use the cover plate that is 6-1/2" wide). The cover plate prevents combustion air from entering the front of the stove.


Remove the two screws on the cover plate to remove the piece that fits over the air control rod. Then replace the piece when the cover plate is in place.




### Rear Blower Installation (Part # 99000138)

The rear blower improves heat transfer by pushing heated air through the convection channel. Operating instructions are described in the section "Blower Operation".


- 1 The stove should be in place with the legs installed prior to installing the rear blower.
- 2 Follow the directions below to install the thermodisk.



- 3 Install the wire clip following the directions below.



- 4 Attach the blower following the directions below.




## Outside Air Boot Installation (Part number 99200134)


The outside air boot routes outside air to the stove for combustion. Refer to the section "Outside Air Requirements" for installation concerns. The directions below detail installation.

- 1 Install the cover plate following the directions below (use the cover plate that is 6-1/2" wide). The cover plate prevents combustion air from entering the front of the stove.

Remove the two screws on the cover plate to remove the piece that fits over the air control rod. Then replace the piece when the cover plate is in place.



- 2 Refer to the illustration below to determine the location and size of the hole penetrating the floor and hearth. The knock-out (which is pre-removed) is 6-3/8" behind the face of the stove - it is 8" wide and 4-1/4" deep. Cut the hole prior to locating the stove.
- 3 Attach gasket to the bottom edge of the lower air boot section (near the screen). Attach gasket on top of the flanges on the upper air boot section. Slide the two sections together with both seams facing the rear (do not attach the two sections at this time).
- 4 Follow the directions below for attaching the upper section of the air boot (with gasket) to the stove.
- 5 Slide the lower section down until it contacts the hearth. Attach the two sections together following the directions below




## Surround Panels

### Rectangular Panels:


| <u>SURROUND PANEL SIZE</u> | <u>HEIGHT</u> | <u>WIDTH</u> |
|----------------------------|---------------|--------------|
| 8"                         | 28-1/4"       | 40-1/8"      |
| 10"                        | 30-1/4"       | 44-1/8"      |

### Arched Panels (Part # 99300108)





### Installation Instructions

1. With the insert 12" from the fireplace, install the side surround panels (see the directions below).




2. Adjust the position of the side panels so they are: 1) flush with the bottom of the insert; 2) both the same distance back from the front of the insert; 3) perpendicular to the floor (use the top panel, if necessary, to judge alignment). Tighten the screws that hold the side panels in place.
3. Place the insert into the fireplace and connect the flue (if using a positive or direct connection). Install the top panel and trim following the directions below.



## Front Blower (part # 99000128)


### To Switch The Power Cord To The Left Side:

Use a pair of pliers to disconnect the strain relief which holds the power cord in place. With the power cord slackened, the mox connectors that attach the power cord to the blower assembly may be disconnected. Pry the button plug from the left side of the blower assembly and insert it into the hole on the right side. Pull the left side mox connector out from behind the deflection plate and cut the nylon tie that holds the wire back. Insert the mox connector on the power cord through the hole on the left side of the blower assembly and attach it to the left side mox connector. Route the wire directly behind the blower cage. Place the strain relief over the power cord (it should be in the same location on the power cord that it was before – approximately 2" from where the wires split). Insert the strain relief into the hole on the left side until the strain relief locks in place. Make sure the power cord, wires, or mox assembly do not protrude into the opening of the blower.



### Installation Instructions

1. Remove the two screws above the air control and beneath the ashlip. Place the blower assembly underneath the ashlip and replace the removed the two screws. Before tightening the screws with a 3/8" nutdriver, lift the blower up so it tucks underneath the ashlip.



2. Plug the power cord running from the control box into a grounded 110 volt electrical outlet.



|                                             |    |                                                |    |
|---------------------------------------------|----|------------------------------------------------|----|
| Air Control.....                            | 25 | Noise (Normal Operating Sounds) .....          | 26 |
| Air Tube Part Number .....                  | 33 | Non-Combustible Alcove .....                   | 13 |
| Air Tube Removal & Replacement.....         | 34 | Opening the Door .....                         | 23 |
| Alcove .....                                | 13 | Operation .....                                | 18 |
| Ash Disposal.....                           | 29 | Outside Air Boot Installation .....            | 43 |
| Baffle Parts .....                          | 33 | Outside Air .....                              | 12 |
| Baffle Removal and Replacement.....         | 34 | Over-Firing the Stove.....                     | 23 |
| Blower Cleaning .....                       | 31 | Overnight Burn.....                            | 26 |
| Blower Does Not Run (Troubleshooting) ..... | 28 | Paint (Touch-Up Paint) .....                   | 31 |
| Blower Installation (rear) .....            | 42 | Paint Curing .....                             | 23 |
| Blower Operation (optional).....            | 26 | Rear Blower Installation.....                  | 42 |
| Burn Rate .....                             | 25 | Re-Loading the Stove .....                     | 26 |
| Cathedral Ceiling .....                     | 15 | Safety Label.....                              | 36 |
| Ceiling Penetration .....                   | 10 | Safety Precautions.....                        | 4  |
| Chimney Cleaning .....                      | 30 | Smell (from paint curing) .....                | 23 |
| Chimney Inspection (Creosote).....          | 30 | Smoke Enters Room (Troubleshooting).....       | 28 |
| Chimney Requirements.....                   | 10 | Sounds (Normal Operating Sounds) .....         | 26 |
| Chimney Termination Requirements.....       | 12 | Starting a Fire .....                          | 24 |
| Cleaning the Ash .....                      | 29 | Stove Does Not Burn Long Enough .....          | 28 |
| Cleaning the Glass .....                    | 29 | Stove is Not Hot Enough (Troubleshooting)..... | 28 |
| Clearances (stove) .....                    | 8  | Table of Contents .....                        | 3  |
| Close Clearance Connectors .....            | 8  | Touch-Up Paint.....                            | 31 |
| Connector Requirements .....                | 10 | Troubleshooting (Operation).....               | 28 |
| Creosote Check.....                         | 30 | Warranty Card .....                            | 2  |
| Daily Maintenance.....                      | 29 | Warranty .....                                 | 35 |
| Dimensions.....                             | 6  | Wood.....                                      | 27 |
| Door and Glass Inspection .....             | 30 | Yearly Maintenance .....                       | 31 |
| Door Assembly .....                         | 32 |                                                |    |
| Door Gasket Replacement .....               | 32 |                                                |    |
| Door Handle Replacement .....               | 32 |                                                |    |
| Door Opening .....                          | 23 |                                                |    |
| Door Parts .....                            | 32 |                                                |    |
| Draft Performance .....                     | 10 |                                                |    |
| Elbows (Chimney) .....                      | 10 |                                                |    |
| Emissions .....                             | 6  |                                                |    |
| EPA Approval .....                          | 6  |                                                |    |
| Exterior Chimney .....                      | 12 |                                                |    |
| Features .....                              | 6  |                                                |    |
| Fire Starting .....                         | 24 |                                                |    |
| Firebox Assembly .....                      | 33 |                                                |    |
| Firebox Parts .....                         | 33 |                                                |    |
| Firebrick and Baffle Inspection .....       | 31 |                                                |    |
| Firebrick Removal & Replacement.....        | 33 |                                                |    |
| Floor Protection Requirements (stove) ..... | 8  |                                                |    |
| Glass Cleaning .....                        | 29 |                                                |    |
| Glass Replacement .....                     | 32 |                                                |    |
| Hearth (Floor Protection - Stove) .....     | 8  |                                                |    |
| Hearth Stove.....                           | 17 |                                                |    |
| Heating Specifications.....                 | 6  |                                                |    |
| Hints for Burns.....                        | 27 |                                                |    |
| Installation Options .....                  | 6  |                                                |    |
| Installation (stove) .....                  | 7  |                                                |    |
| Leg Installation .....                      | 40 |                                                |    |
| Listing Label .....                         | 36 |                                                |    |
| Maintenance .....                           | 29 |                                                |    |
| Mobile Home Requirements.....               | 14 |                                                |    |
| Monthly Maintenance .....                   | 30 |                                                |    |